

VDK, VDM

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Казань (843)206-01-48	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54
Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астрахань (8512)99-46-04	Калуга (4842)92-23-67	Омск (3812)21-46-40	Ставрополь (8652)20-65-13
Барнаул (3852)73-04-60	Кемерово (3842)65-04-62	Орел (4862)44-53-42	Сургут (3462)77-98-35
Белгород (4722)40-23-64	Киров (8332)68-02-04	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Брянск (4832)59-03-52	Краснодар (861)203-40-90	Пенза (8412)22-31-16	Томск (3822)98-41-53
Владивосток (423)249-28-31	Красноярск (391)204-63-61	Пермь (342)205-81-47	Тула (4872)74-02-29
Волгоград (844)278-03-48	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Вологда (8172)26-41-59	Липецк (4742)52-20-81	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Воронеж (473)204-51-73	Магнитогорск (3519)55-03-13	Самара (846)206-03-16	Уфа (347)229-48-12
Екатеринбург (343)384-55-89	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Иваново (4932)77-34-06	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Набережные Челны (8552)20-53-41	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Иркутск (395)279-98-46	Нижний Новгород (831)429-08-12	Симферополь (3652)67-13-56	Ярославль (4852)69-52-93
Россия (495)268-04-70	Киргизия (996)312-96-26-47	Казахстан (7172)727-132	

VDK



Wear parts set, piston pressure reducer, G1 / 2 "-DN15, FKM, piston diameter: 63mm

Item number: VDK330X06323

Wear parts set, piston pressure reducer, G1 / 2 "-DN15
FKM, piston diameter: 63mm



Wear parts set, piston pressure reducer, G3 / 4 "-DN20, FKM, piston diameter: 63mm

Item number: VDK330X06324

Wear parts set, piston pressure reducer, G3 / 4 "-DN20
FKM, piston diameter: 63mm



Wear parts set, piston pressure reducer, G1 "-DN25, FKM, piston diameter: 63mm

Item number: VDK330X06325

Wear parts set, piston pressure reducer, G1 "-DN25
FKM, piston diameter: 63mm



Wear parts set, piston pressure min., G1 1 / 4 "+11/2", FKM, piston diameter: 63mm

Item number: VDK330X06327

Wear parts set, piston pressure min., G1 1 / 4 "+11/2"
FKM, piston diameter: 63mm



Wear parts set, piston pressure min., G1 1 / 4 "+11/2", FKM, piston diameter: 80mm

Item number: VDK330X08027

Wear parts set, piston pressure min., G1 1 / 4 "+11/2"
FKM, piston diameter: 80mm



Wear parts set, piston pressure reducer, G2 "-DN50, FKM, piston diameter: 80mm

Item number: VDK330X08028

Wear parts set, piston pressure reducer, G2 "-DN50
FKM, piston diameter: 80mm



Wear parts set, piston pressure reducer, G1 / 2 "-DN15, EPDM, piston diameter: 63mm

Item number: VDK340X06323

Wear parts set, piston pressure reducer, G1 / 2 "-DN15
EPDM, piston diameter: 63mm



Wear parts set, piston pressure reducer, G3 / 4 "-DN20, EPDM, piston diameter: 63mm

Item number: VDK340X06324

Wear parts set, piston pressure reducer, G3 / 4 "-DN20
EPDM, piston diameter: 63mm



Wear parts set, piston pressure reducer, G1 "-DN25, EPDM, piston diameter: 63mm

Item number: VDK340X06325

Wear parts set, piston pressure reducer, G1 "-DN25
EPDM, piston diameter: 63mm



Wear parts set, piston pressure min., G11 / 4 "+11/2", EPDM, piston diameter: 63mm

Item number: VDK340X06327

Wear parts set, piston pressure min., G11 / 4 "+11/2"
EPDM, piston diameter: 63mm



Wear parts set, piston pressure reducer, G2 "-DN50, EPDM, piston diameter: 63mm

Item number: VDK340X06328

Wear parts set, piston pressure reducer, G2 "-DN50
EPDM, piston diameter: 63mm



Wear parts set, piston pressure min., G11 / 4 "+11/2", EPDM, piston diameter: 80mm

Item number: VDK340X08027

Wear parts set, piston pressure min., G11 / 4 "+11/2"
EPDM, piston diameter: 80mm



Wear parts set, piston pressure reducer, G2 "-DN50, EPDM, piston diameter: 80mm

Item number: VDK340X08028

Wear parts set, piston pressure reducer, G2 "-DN50
EPDM, piston diameter: 80mm

VDM



Wearing parts set pressure reducer DM1, G1 / 4 "-G1 / 2", Edel / FKM, input pressure: 8 bar, output pressure: 2-3 bar

Item number: VDM3301XXX-01 / XX

Wearing parts set pressure reducer DM1, G1 / 4 "-G1 / 2"
Edel / FKM, input pressure: 8 bar , output pressure: 2-3 bar



Wearing parts set pressure reducer DM1, G1 / 4 "-G1 / 2", Edel / FKM, input pressure: 25bar, output pressure: 2-10bar

Item number: VDM3301XXX-03 / XX

Wearing parts set pressure reducer DM1, G1 / 4 "-G1 / 2"
Edel / FKM, input pressure: 25bar , output pressure: 2-10bar



Wearing parts set pressure reducer DM3, G1 / 2 "-G1", Edel / FKM, input pressure: 8 bar, output pressure: 2-3 bar

Item number: VDM3303XXX-01 / XX

Wearing parts set pressure reducer DM3, G1 / 2 "-G1"
Edel / FKM, input pressure: 8 bar , output pressure: 2-3 bar



Wearing parts set pressure reducer DM3, G1 / 2 "-G1", Edel / FKM, input pressure: 25bar, output pressure: 2-10bar

Item number: VDM3303XXX-03 / XX

Wearing parts set pressure reducer DM3, G1 / 2 "-G1"
Edel / FKM, input pressure: 25bar , output pressure: 2-10bar



Wearing parts set pressure reducer DM5, G1 "-G2", Edel / FKM, input pressure: 8bar, output pressure: 5-3bar

Item number: VDM3305XXX-01 / XX

Wearing parts set pressure reducer DM5, G1 "-G2"
Edel / FKM, input pressure: 8bar, output pressure: 5-3bar



Wearing parts set pressure reducer DM5, G1 "-G2", Edel / FKM, input pressure: 25bar, output pressure: 2-10bar

Item number: VDM3305XXX-03 / XX

Wearing parts set pressure reducer DM5, G1 "-G2"
Edel / FKM, input pressure: 25bar, output pressure: 2-10bar



Wearing parts set pressure reducer DM5, G1 "-G2", Edel / FKM, input pressure: 25bar, output pressure: 6-16bar

Item number: VDM3305XXX-05 / XX

Wearing parts set pressure reducer DM5, G1 "-G2"
Edel / FKM, input pressure: 25bar, output pressure: 6-16bar



Wearing parts set pressure reducer DM1, G1 / 4 "-G1 / 2", noble / EPDM, input pressure: 8bar, output pressure: 2-3bar

Item number: VDM3401XXX-01 / XX

Wearing parts set pressure reducer DM1, G1 / 4 "-G1 / 2"
noble / EPDM, input pressure: 8 bar , output pressure: 2-3 bar



Wearing parts set pressure reducer DM1, G1 / 4 "-G1 / 2", noble / EPDM, input pressure: 25bar, output pressure: 2-10bar

Item number: VDM3401XXX-03 / XX

Verschleißteilset Druckminderer DM1, G1/4"-G1/2"
Edel/EPDM, Eingangsdr.:25bar, Ausgangsdr.:2-10bar

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Казань (843)206-01-48	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54
Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астрахань (8512)99-46-04	Калуга (4842)92-23-67	Омск (3812)21-46-40	Ставрополь (8652)20-65-13
Барнаул (3852)73-04-60	Кемерово (3842)65-04-62	Орел (4862)44-53-42	Сургут (3462)77-98-35
Белгород (4722)40-23-64	Киров (8332)68-02-04	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Брянск (4832)59-03-52	Краснодар (861)203-40-90	Пенза (8412)22-31-16	Томск (3822)98-41-53
Владивосток (423)249-28-31	Красноярск (391)204-63-61	Пермь (342)205-81-47	Тула (4872)74-02-29
Волгоград (844)278-03-48	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Вологда (8172)26-41-59	Липецк (4742)52-20-81	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Воронеж (473)204-51-73	Магнитогорск (3519)55-03-13	Самара (846)206-03-16	Уфа (347)229-48-12
Екатеринбург (343)384-55-89	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40	Хабаровск (4212)92-98-04
Иваново (4932)77-34-06	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Набережные Челны (8552)20-53-41	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Иркутск (395)279-98-46	Нижний Новгород (831)429-08-12	Симферополь (3652)67-13-56	Ярославль (4852)69-52-93
Россия (495)268-04-70	Киргизия (996)312-96-26-47	Казахстан (7172)727-132	

Эл. почта efg@nt-rt.ru || Сайт: <https://end.nt-rt.ru/>